

QC Dual SUP Rack

Instructions

Part #: 1028024

Parts List			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	2	1003790	QC Vertical Bumper Bracket Weldment
2	2	1003119	Slider Leg 37.75" Vert. Roto Bumper
3	6	1001815	Cap Blue #14 - 2.0x2.0x2.0
4	8	1001956	Bolt Carriage 3/8-16 x 1.0 SS 304
5	8	1001802	Nut Flange 3/8-16 Brass
6	2	1028021	Prt Angle 2.0x2.0x.25x26.0
7	16	1002599	Washer Flat 3/8 SS
8	8	1002434	Bolt Hex 3/8-16 x 3.5 SS 304
9	8	1001805	Nut Nyloc 3/8-16 Brass
10	2	1028020	Wdmt Paddleboard Rack Arm
11	2	1028022	HDPE SUP Rack Board

Failure to follow instructions may result in personal injury and may invalidate the applicable warranty.

Step 1. Attach QC accessory bracket (sold separately) to QC vertical bumper bracket weldment using hardware from QC accessory bracket 3/8 x 1 carriage bolts and 3/8 flange nuts.

Step 2. Attach QC vertical bumper bracket to slider leg (at desired height) using 3/8 x 1 carriage bolts in the offset t-slot of the slider leg and secure using two 3/8 flange nuts.

Step 3. Attach wdmt paddleboard rack arm to slider leg using 3/8 x 1 carriage bolts in the centered t-slot of the slider leg and secure using two 3/8 flange nuts (set to desired height before tightening nuts).

Step 4. Place 3/8 flat washers onto four 3/8 x 3-1/2 hex bolts. Insert bolts through drilled angle, then the bottom of the SUP rack board, and then the wdmt paddleboard rack arm. Place 3/8 flat washers onto ends of the bolts and secure in place using 3/8 nylock nuts.

Step 5. Place blue caps over the top and bottom ends of the slider legs and end of rack arm as shown. Adjust SUP rack height and spacing to fit your application. Tighten all hardware.

