

## Single 12 Volt LED Flexible Canopy Light with Remote

Part #: 1030248

Parts List	
Qty	Description
1	Battery Cable
1	RF Receiver
1	Power Cable
1	LED Light
15	Zip Ties



**Step 1.** Connect the battery cable to one 12 volt battery. Attach the black wire to the negative (-) battery post and the red wire to the positive (+) battery post.

**Step 2.** Plug the LED controller into the battery cable. Make sure to plug in the correct side of the controller. The LED controller has one end labelled "5-24V" (left side), this is the end that should be plugged into the battery side.

**Step 3.** Plug in the controller end labelled "LED" (right side) to the 16ft wire. Make sure the 16ft wire end labelled battery is the end plugged into the LED controller.

**Step 4.** Plug in the LED light to the "light" end of the 16ft wire. Attach light to canopy frame using zip ties. Use remote to turn on, off, and adjust brightness.

To add second light order:

1030246 - Single Light Kit No Remote


1030251 - Y-Connector



Pressing the "Brighter" and "Dimmer" button at the same time will initiate a strobe setting.

When the strobe setting is active, the speed can be adjusted using the "Brighter" button to flash faster and the "Dimmer" button to flash slower.

Pressing the On/Off button while in the strobe setting will turn off the strobe function.



**Warning: Only connect the RF Receiver to ONE 12v Battery**

