Pontoon Rail Bracket for Bent Rack

Instructions

Part #: 1007007

Parts List			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	4	1003843	Pontoon Rail Bracket Bent Rack Lower
2	4	1005762	Pontoon Rail Bracket Bent Rack Upper
3	4	1026697	2x4x12" Carpeted Wood (Sold Separately)
4	8	1002432	Bolt 3/8 x 3.0
5	4	1002382	Bolt 1/2 x 3.0
6	4	1001792	NUT 1/2
7	24	1001960	Bolt Carriage 3/8 x 2.5
8	32	1001802	Nut Flange 3/8
9	4	1002565	Washer Flat 1/2 SS 304
10	2	1026688	2x8x14' Carpeted Wood (Sold Separately)

Failure to follow instructions may result in personal injury and may invalidate the applicable warranty.

Step 1. Place the lower brackets onto the rack of the lift. Secure in place using two 3/8 x 3 hex bolts and two 3/8 flange nuts for each lower bracket. Leave loose until placed in desired location on lift.

Step 2. Place upper brackets into the lower bracket and secure at desired height using one 1/2 x 3 hex bolt and one 1/2 flat washer and 1/2 hex nut per bracket.

Step 3. Attach the small bunk boards to the top of the upper brackets using two 3/8 x 2-1/2 carriage bolts and two 3/8 flange nuts for each piece.

Step 4. Attach the full length bunk boards to the upper brackets as shown. Use four 3/8 x 2-1/2 carriage bolts and four 3/8 flange nuts to secure the bunk boards in each place.

Step 5. Adjust the spacing and height of the bunks to fit your application.



