

Dock Bumper Horizontal Adaptor

Instructions

Part #: 1004186

| Parts List | | | |
|------------|-----|-------------|-----------------------------------|
| ITEM | QTY | PART NUMBER | DESCRIPTION |
| 1 | 1 | 1003119 | Slider Leg 37.75" Roto Bumper |
| 2 | 1 | 1006730 | TS9 Accessory Connector |
| 2 | 1 | 1006706 | RS4 Accessory Connector |
| 2 | 1 | 1006708 | RS7 Accessory Connector |
| 2 | 1 | 1006608 | Poly Dock Accessory Connector |
| 3 | 1 | 1004186 | Horizontal Adaptor |
| 4 | 4 | 1001956 | Bolt Carriage 3/8-16 x 1.0 SS 304 |
| 5 | 4 | 1001802 | Nut Flange 3/8-16 Brass |

Failure to follow instructions may result in personal injury and may invalidate the applicable warranty.

Note: The Horizontal Adaptor allows a Vertical Dock Bumper to be configured Horizontally. Hardware is included with the Accessory Bracket. Vertical Dock Bumper and Bracket sold separately.

Step 1. Attach Accessory bracket to dock frame by inserting top of bracket into top of dock frame rail. Secure by threading t-handle into bottom of bracket and tightening to dock frame.

Step 2. Using two flanged nuts and two carriage bolts, secure the horizontal adaptor angle to the bracket.

Step 3. Slide two carriage bolts into the t-rail of the bumper tube. Secure the bumper to the horizontal adapter using the flange nuts and carriage bolts in the bumper tube.

Step 4. Secure the bumper to the bumper tube.

